



ALLMATIC BRO4WN/ ALLMATIC BRO1WN/ ALLMATIC BRO2WN

1. Locate the secret button on the front of your Allmatic remote and press it with something like a paperclip
2. Press the button on your existing remote control, which you normally use to operate your system
3. Press the button on your new remote control that you would like to add in to the system
4. Your new remote control is now programmed