



ALLMATIC BR022W Receiver

1. Place yourself near the radio receiver of the installation 1 to 2 meters
2. Push a metal paper clip into the small hole in the back of the remote (or press once the secret button on the cell side).
3. The LED on the remote control is on for 1 second and then turns off.
4. The receiver goes into "record" mode for 10 seconds.
5. Take the new remote control.
6. Press any button on the new remote control for 1 second.