



CAME TOP432

Programming must be done button by button

1. Press simultaneously both buttons on your new remote control until the LED flashes then release
2. Press the first button on the new remote control, the LED lightens and remains on
3. Within the next 10 seconds, place both remotes head to bottom
4. Press the first button on the old remote control
5. The new remote control flashes 3 times
6. The first button is now programmed

NOTE: Repeat the same procedure for the second button