



Manual

How to Programme your REMOTE CHAMBERLAIN 4330E – 4335E



How to program your new remote control:

1. Approach your motor so you are standing a few feet away from it.
2. Press the button on your new remote control. Keep it pressed down (1).
3. On the panel of control of your motor, located behind it, press the programming button "Smart" (2) while keeping pressed down the button on your new remote control.
4. The LED light on the motor blinks once (3). Let the buttons go.
5. Wait 10 seconds.
6. Your new remote control is programmed.