

Your Programming Instructions for your new remote control

KING-GATES Myo 4C - Stylo 4

How to program your new remote control:

Remote-to-remote programming:

1. Press the button on your new remote control that you wish to program. The LED light on your new remote control blinks.
2. Approach your new remote control to your already-programmed remote control.
3. While keeping the button on your new remote control pressed down, press the same button on your already-programmed remote control.
4. The LED light on your new remote control blinks fast.
5. Wait 10 seconds.
6. Your new remote control is programmed.