

INSTRUCTIONS

BECKER SC431



NOTE: Before entering this SC431 transmitter, make sure that a master transmitter has been already programmed into the receiver and the motor has learned the upper and lower stops.

Put the receiver into learn mode:

- 1. Switch off the receiver's power supply and reconnect after 5 seconds OR activate the programming button on the radio-controlled receiver switch.
- 2. The receiver will be in 'learn' mode for 3 minutes
- Learn master transmitter:

When the receiver is in `Learn' mode, press the programming button until the receiver indicates that the learn process is completed.

Visit our website: www.alloremotecontrol.com