




### BECKER TC445



## **Programming with the receiver:**

Switch off the receiver's power supply and reconnect after 5 seconds OR activate the 'learn' button or the radio controlled receiver switch.

The receiver will be then in learn mode after 3 minutes

When the receiver is in learn mode, press the learn button until it indicates that the learn process has been successfully completed.