



CAME TOP 432 EE/CAME TOP 432NA

Programming with an already programmed remote control transmitter:

- 1 - Press the 2 buttons on your already programmed remote control simultaneously until the LED starts flashing more quickly
 - 2 - Then press the button to activate, the LED comes on
 - 3 - Within 10 seconds, place the active transmitter on its back and press the button to duplicate for a few seconds.
- After saving, the LED will flash 3 times and the transmitter will be ready for use.

To program another button, repeat the same procedure

Programming directly on the receiver:

1. Open the casing of your receiver. It is located next to your motor.
2. On the receiver circuit board, press the button CH1.
3. While keeping the button CH1 pressed down, press the first button on your new remote control. Let the buttons go.
4. On the receiver circuit board, press the button CH2.
5. While keeping the button CH2 pressed down, press the second button on your new remote control. Let the buttons go.
6. Your new remote control is programmed.