



CAME TOP 434EE

Programming must be done button by button

1. Press simultaneously both buttons on your new remote control until the LED flashes then release them
 2. Press the first button on your new remote control until the LED lightens up continuously
 3. Within the next 10 seconds, place both remote control head to bottom
 4. Press the first button on your old remote control
 5. Your new remote control will flash 3 times
- Your new remote control is now programmed