



CAME TOP432EV

- 1 Press both top buttons on your new remote control at once and keep them pressed until the LED light on your new remote control starts to blink.
- 2 Press the left button of your new remote control. The LED on your new remote control will light up constantly.
- 3 While holding the button pressed of your new remote control, place the already programmed remote control next (slightly touch) to the new remote control and press the same button of your already programmed remote control. Keep the button on both remote control pressed until the LED of the new remote control flashes 3 times.
- 4 This means your new remote control has been programmed!