



DEA

1. Press and hold the button you would like to use and any of the other buttons simultaneously until the light is on
2. Release the button that you are not going to use
3. A red LED will start flashing
4. Take your working remote control and place the nose close to your new remote control
5. Press the button you normally use to operate your gate and garage door system (keep holding the button that you want to program on your new remote control simultaneously)
6. You will notice that the LED is flashing continuously.
7. Your new remote control is now programmed