



NICE VERY

Entering the code for the VERY VE series:

Enter the code with the two transmitter buttons as follows:

1. Press down both buttons on the transmitter until the LED lights up then start entering the code sequence within 5 seconds.
2. Press button T1 if dip switch 1 on the receiver is ON, otherwise button T2 if this dip switch is OFF
3. Repeat point 2 for all the 10 dip switches of the receiver. The is obtained with the sequence T1-T1-T2-T1-T1-T1-T2-T2-T2-T1.
4. After the 10th dip switch is entered the LED will start flashing rapidly for seconds. If no button is pressed while the LED flashes, the code will be memorised,

If there is more than one VERY VE's to programme, it may be easier to use the relative CVU programming unit, this can even set up two different codes for the two buttons.

Selecting the transmitter buttons:

If necessary, the "value" of the buttons in the transmitters can be modified, that is, for example, by pressing button T1 to transmit the button T2 code.

With the VERY VE transmitters selection can only be made by using the relative CVU programming unit.