



PRASTEL MR1E

1. Power up the receiver correctly.
2. Press button P1: the red led lights up indicating that programming is in progress.
3. Carry out a transmission pressing any transmitter button.
4. The code is inserted into the memory. The led flashes during insertion. At the end the led returns to the non-flashing state, indicating that a new code may be inserted.
5. Memorise all the transmitters by carrying out a transmission with each one.
6. At the end of the operation press button P1 again to exit from the procedure. The led goes out. Exit from the programme comes about automatically in any case 10 seconds after the last memorisation.
7. The codes remain in the memory even if the power supply is cut.

Total cancellation of codes:

1. Hold button P1 pressed until the red led starts flashing.
2. Press button P1 again within 6 seconds to confirm cancellation. Confirmation is indicated by the led flashing with greater frequency.