SOMFY MULTI-APPLICATION

1. Take the remote control that manages only the shutter you wish to program

2. Press and hold the button "PROG" for 4 seconds until the roller shutter moves back and forth

3. Remove the cover of Somfy Multi-Application and press the button "PROG" at the back your your remote

4. Press a button you wish to program for controlling the system, (your roller shutter will move back and forth)