



ALLO
REMOTECONTROL

INSTRUCTIONS

CAME TWIN

- 1 - Press the 2 keys together until the LED starts flashing more quickly
- 2 - Then press the key to activate (the LED comes on);
- 3 - Within 10", place the active transmitter on its back and press the key to duplicate for a few seconds. After saving, the LED will flash 3 times.

For another key, repeat steps 1, 2 and 3

Visit our website: www.Alloremotecontrol.com