



ALLO
REMOTECONTROL

INSTRUCTIONS

PROGET ETY 433 4N

Registration: press and hold the button MEM in the receiver (PRG on the control unit). The receiver's LED blinks slowly. Press the button of the remote control you wish to record and bring it closer until the light of the receiver's LED stays always on. When pressing keep your remote control far from metallic parts, if you are inside your car, bring it close to the windows; in order to be recognized by the receiver you must press for at least one second and avoid giving multiple commands in a short period of time because the commands may not be well understood by the receiver.

COPYING PROCEDURE

Press and hold both buttons on ETY 433 4N the LED blinks, after five seconds it stays on. Continue pressing ONLY the button of ETY-433 2C that you want to program and release the other one, the LED turns off (image 1).

Press the button of the remote control to be copied and get closer to the other one (image 2) until the LED of EtY 433 4N turns on the operation is concluded. Test the remote control which learned the code.

We can recognise that the button was programmed with a code different than "B&B Rolling Code" looking at the blinking of the transmitter that should be of lower frequency. For some type of remote controls less powerful (anti-thief used) the operation can be harder. It will be possible that you'll need to place the remote control over the EtY 433 4N to find the best communication between the antennas of both transmitters. We can recognise that the button was programmed with a code different than "B&B Rolling Code" looking at the blinking of the transmitter that should be of lower frequency.

Warning! ETY 433 4N copies one button at the time, if necessary repeat the operation for the other buttons. Verify the working conditions of the button you just program.

Visit our website: www.alloremotecontrol.com



Image 1



/ Image 2