



**ALLO**  
REMOTECONTROL

INSTRUCTIONS

**PUJOL**

**Procedure for direct programming of the receiver:**

Step 1. Open the receiver. Inside you will find a small button, where is screen-printed PROG-RESET

Step 2. Press this button and you will hear a beep sound.

Step 3. Press the button on your remote control to be programmed in the receiver.

Step 4. Wait until the receiver exits programming.