



SUPERIOR FREEDOM MICRO USB

1. Insert brand new batteries to your new remote control
2. Make sure to have your programming cable and the reference of your remote control
3. On your pc, access the website "www.telecontrol.tv"
4. Click on "download" then the program to be installed "Superior Software [Download Area]"
5. Click then on Download Software for USB programmable remote controls



























1. After installing your remote control, an icon pops up
2. Double-click on OK
3. Plug the programming cable between your remote control and the USB port of your PC
4. Enter the brand and the model
5. Double click on the model of your remote control



Additional functions are available when you press the key "SHIFT"

SHIFT KEY



 POWER	7 7	 VOL+	 INFO
 MUTE	8 8	 VOL-	 EPG GUIDE
MENU MENU	9 9	 CH+	 FAV FAV
EXIT EXIT	0 0	 CH-	 AUTO/ PICTURE
1 1	 AV/ INPUT	 UP	 STILL
2 2	 -/-- LIST	 DOWN	 HOLD/ FREEZE
3 3	 DISPLAY	OK OK/ ENTER	 RED
4 4	 TELETEXT BIG	BACK BACK/ RETURN	 GREEN
5 5	 TELETEXT MIX	SLEEP SLEEP	 YELLOW
6 6	 TXT	TV/DTV TV/ DIGITAL TV	 BLUE