


BELFOX DHS-BELFOX HS-868-JANE F-JANE V



- 1. Place your existing remote pointing the B area of Jane F
- 2. Press and hold one of the A button, that you want to clone
- 3. After 6 seconds, the blue LED starts to flash entering in clone mode
- 4. When the blue LED flashes, press and hold the channel's button of original remote and wait until Jane's blue LED stops flashing and becomes fixed.

When the blue light LED is fixed, it means that the original code is cloned and transmitted from your old remote control into Jane F

- 1. The blue led remains steady for 2 seconds and then it turns off
- 2. Release the A button and the button of the original remote

To duplicate the code from a second channel choose another A button and **repeat the operation**.

If the blue LED turns off after flashing, it means that the cloning process is not active and it still operates with the old code or the code previously duplicated. Repeat the operation by pressing the button on your old remote control after the blue LED starts flashing.