




BECKER VC421



1 Antenna

2 Connecting terminals

3 Programming button

4 Transmission control light

How to program BECKER VC421?

NOTE: Before entering this VC421 transmitter, make sure that a master transmitter has been already programmed into the receiver and the motor has learned the upper and lower stops.

1. Press the programming button of the receiver until acknowledgement is given by the receiver
2. Press the programming button of the new transmitter until acknowledgement is given by the receiver
3. Then press the programming button of the new transmitter to be learnt once again

The receiver will indicate when the learn process is completed.