



BENINCA T2WK & T4WK

Programming from an already activated remote control:

1. Press and hold the 1st button on the new remote, the light flashes after 5 seconds keep holding this button until programming is complete.
2. Place the working remote nose to nose with the new remote then press and hold in the button which you would like to copy
3. The light on the new remote will go off
4. Your new remote control is now programmed