



ALLO
REMOTECONTROL

INSTRUCTIONS

CAME TAM432SA

Programming with an already activated transmitter:

1. press the 2 keys together until the LED starts flashing more quickly; flashing more quickly;
2. then press the key to activate (the LED comes on)
3. Within 10 seconds, place the master transmitter on its back and press the key to duplicate for a few seconds
4. The LED will flash 3 times and the transmitter will flash 3 times

Your new remote control is now programmed!

Visit our website: www.Alloremotecontrol.com