



DEA GT4

Programming from an already programmed transmitter:

1. Place your original remote and your new remote head to head
2. Press and hold "Button 1" on your new control. The LED on your new remote control will light up.
3. While holding "Button 1", press "Button 2" four times.
4. Release all of the buttons. The LED on your new remote control will flash slowly.
5. While the LED is flashing, press and hold a button on your old remote control until the LED on your Multi 2 remote flashes faster.
6. Release the button on your old remote
7. While the LED on your new remote flashes faster, press and hold a button on your new Multi 2 remote (button 1, 2, 3 or 4) until the LED on your new remote goes out.
8. You have now successfully cloned that button on your old remote into one of the buttons on your new one.

Programming on a receiver with no LCD screen:

1. Open the case of your receiver box. it is next to your motor.
2. Press the programming button on the circuit board of the receiver and then let it go (button ENR, MEMO, PROG, or RESET, depending on the model).
3. The LED light on the receiver comes on or blinks.
4. Press a button on your new remote control for 1 second.
5. Release it. The LED light on the receiver goes out immediately or in the following 10 seconds depending on the model.
6. Your new remote control is now programmed.

RECEIVER WITH A DIGITAL SCREEN:

1. Open the case of your receiver box. It is next to your motor.
2. Press the buttons + or - on the receiver circuit board until you notice the entry P005 on the digital screen.
3. Press OK. The LED lights up.
4. Press a button on your new remote control for 1 second
5. Wait 10 seconds.
6. Your new remote control is now programmed.