

FAAC 433 DS1, 433 DS2 & 433 DS3

Programming from an already activated remote control:

- 1. Press and hold both buttons on the working remote control until the light flashes
- 2. The LED of your working remote control will flash 4 times, release 1 button and keep holding the other one
- 3. Press and hold in the button you wish to program on the new remote control
- 4. Place both remotes back to back without releasing buttons
- 5. The LED of your working remote control will flash 3 times
- 6. Release all the buttons
- 7. The first button of your new remote control is now programmed!