



NICE SMILO

Programming from an already activated transmitter:

1. On the NEW transmitter: Press the button for at least 5 seconds, then release.
2. On the OLD transmitter: Press and slowly release the button 3 times. 1s 1s 1s 3.
3. On the NEW transmitter: Press and slowly release the button once. x1

N.B.: if there are other transmitters to memorise, repeat all the above steps for each new transmitter

Programming directly on the receiver:

1. Press and hold down the receiver button for at least 3 seconds 3s
2. Release the button when the led lights up 3. Within 10 seconds press any button on the transmitter to memorise for at least 2 seconds 2s

N.B.: If the procedure was memorised correctly, the Led on the receiver will flash 3 times. If there are other transmitters to memorise, repeat step 3 within another 10 seconds, if not, the memorisation phase will finish automatically