



PRASTEL MPSTL2E 433MHz

1. Press the hidden button at the back of your old remote control or press the hidden button next to the battery inside your remote control and release it
2. The LED light of your old remote control flashes. Wait 5 seconds. The LED light of your old remote control turns off.
3. During the next 10 seconds, press a button on your new remote control and release it
4. Wait 10 seconds.
5. Your new remote control is programmed.