



**ALLO**  
REMOTECONTROL

INSTRUCTIONS

## BFT B RCB02 / BFT Mitto

1. Take something like a paperclip and press the secret button on your old remote control
2. Press the button that you normally use to operate your gate or door system
3. Release the button
4. Take your new remote control and press and hold both buttons until the light comes on
5. Press the button on your new remote control that you want to use
6. After 20 seconds, your new remote control will be programmed

Visit our website: [www.Alloremotecontrol.com](http://www.Alloremotecontrol.com)