



Jane JQ

Program your new remote control:

1. Place your new JANE remote control and old transmitter as shown below.
2. Press and hold the button on your new remote control that you want to program
3. Simultaneously, press the button your normally use on your old remote control
4. The LED on your new remote control flashes then comes off
5. Release all the buttons
6. Your new remote control is now programmed!

Repeat the procedure for each button you want to program

