





MOTOSTAR 4C



1. Press button 1 on your new remote control and keep it pressed down.
2. While keeping button 1 on your new remote control pressed down, press button 4 on your new remote control. The LED starts to blink. Release both buttons.
3. The LED stays lit for five seconds. During this time, press the button you wish to program on your new remote control and keep it pressed down.
4. While keeping the desired button pressed down, place the old, functional remote control in the target area at the back of the new remote control
5. Press the button on your old remote control that is to be copied.
6. The LED on the new remote control blinks quickly at first and then slowly and regularly. Release both buttons
7. Your new remote control is now programmed!