



NICE HSTSA1

HSTSA1 is a tabletop or wall-mounted support for the HSTS2 touchscreen keypad. It has two rechargeable batteries and a battery charger for recharging them (they are recharged when the touchscreen keypad is mounted on its support). This product is part of the Nice Home System alarm system. Any use other than the use described in this manual should be considered prohibited!

Wall mounting:

- Check that the surface on which the product is to be mounted is sufficiently robust.

- Check that the power supply cable can pass through the opening in the centre of the support fig. 1.

- Do not install the support close to a heat source.

01. Mark the anchorage points on the wall, drill holes, insert the screw anchors provided and pass the power cable through the opening in the centre of the support (fig. 1/A-B-C); 02. Fasten the support in place with the screws supplied (fig. 1/C);

03. Connect up the micro USB connector of the power supply unit provided (fig. 1/D);

04. Hook the support onto the wall and insert the touchscreen keypad (fig. 1/E).

Warnings – Place the support on a flat surface where it will be protected against accidental falls. Assemble the tabletop support: 01. Insert part (b) into support (a) as shown in fig. 2/A; 02. Slide bracket (b) upwards as shown in fig. 2/B; 03. Connect up the micro USB connector of the power supply unit provided (fig. 2/C)

