



SOMMER 4020

Start by identifying the programming button in your receiver unit

Programming must be done button by button:

1. Press the programming button on the receiver unit
2. The LED comes on
3. Press the first button on the remote control
4. To program the second button, press twice the button in the receiver unit
5. The LED lightens up
6. Press the second button on your remote control
7. The light comes off
8. The second button is now programmed
9. To program the third button, press 3 times the button in the receiver unit
10. The LED lightens up
11. Press the third button on your remote control
12. The light comes off

(Repeat the same procedure for button 4)