



**ALLO**  
REMOTECONTROL

INSTRUCTIONS

## TELECO I-LIKE

1. Press the hidden button on your old remote control
2. The receiver emits a few beeps
3. Press one of the buttons of your old remote control
4. The receiver emits a beep and enters into learning mode
5. On your new remote control, press the button you want to program for operating your gate or door system
6. The receiver emits a few beeps
7. Your new remote control is now programmed

Visit our website: [www.Alloremotecontrol.com](http://www.Alloremotecontrol.com)