

INSTRUCTIONS

TORMATIC NOVOTRON 504/ MCHS43-2/ NMNHS433 2

- 1. Press the ch1 button of your receiver, the LED of channel 1 comes on
- 2. Press for 2 seconds the button on your new remote control while the LED of your receiver is flashing
- 3. The LED of your receiver blinks then comes off
- 4. Your new remote control is now programmed

Visit our website: www.Alloremotecontrol.com