


INSTRUCTIONS

V2 heavy2

The programming of the functions and times of the unit is carried out through the configuration menus, accessible and searchable \uparrow , \downarrow and **OK** through the 3 buttons placed next to the display of the unit.



By pressing OK button you can access the programming and configuration menus of each individual parameters

By pressing the \checkmark button you will switch to the next item

By pressing the 1 button you return to the previous item

ACCESS TO MAIN PROGRAMMING MENUS:

Press and hold the OK button until the display shows the desired menu

PRG	MODE
CNT	Total / Service
SET	Learn / Exit
DEF	Load default / Exit

Release the OK button: the display shows the first item in the sub-men or the options available for the function


Visit our website: www.Alloremotecontrol.com

CAUTION: if you do not carry out any operation for more than 1 minute, the unit exits from the programming mode, without storing the settings and changes made are lost.

If necessary, you can reset all parameters to their DEFAULT values

TRAVEL LEARNING:

- 1. Press and hold the OK button until the display shows SET
- 2. Release the OK button: the display shows



- 3. To exit the function, select Exit using the \uparrow \downarrow and press OK to confirm
- 4. To start the learning procedure of the travel select Learn through the buttons \uparrow and \downarrow and press then OK
- 5. Press and hold the button to open the door completely
- 6. Press and hold the button to close the door completely
- 7. Press the OK button to store the travel and exit the function