




### V2 heavy1

The programming of the functions and times of the unit is carried out through the configuration menus, accessible and searchable through the 3 buttons **↑**, **↓** and **OK** placed next to the display of the unit.



By pressing OK button you can access the programming and configuration menus of each individual parameters

By pressing the **↓** button you will switch to the next item

By pressing the **↑** button you return to the previous item

#### ACCESS TO MAIN PROGRAMMING MENUS:

Press and hold the OK button until the display shows the desired menu

PRG	MODE
CNT	Total / Service
SET	Learn / Exit
DEF	Load default / Exit

Release the OK button: the display shows the first item in the sub-men or the options available for the function


Using the buttons **↑ ↓** and **OK** select and edit the parameters needed







CAUTION: if you do not carry out any operation for more than 1 minute, the unit exits from the programming mode, without storing the settings and changes made are lost.

If necessary, you can reset all parameters to their DEFAULT values

#### TRAVEL LEARNING:

1. Press and hold the OK button until the display shows SET
2. Release the OK button: the display shows



3. To exit the function, select Exit using the   and press OK to confirm
4. To start the learning procedure of the travel select Learn through the buttons  and  and press then OK
5. Press and hold the  button to open the door completely
6. Press and hold the  button to close the door completely
7. Press the OK button to store the travel and exit the function