



NICE FLO.R, NICE WAY, NICE ONE, NICE BIO (30.875 Mhz)

All NICE ROLLING CODE remote controls in 433 Mhz are compatible with each other.

For collective installations, **NICE BIO** remote control (BLUE case) and **NICE BIO PORTIS** (BLACK case) are **incompatible**.

To start programming, you must be near the receiver unit

- 1. Take the new remote control and press any button for over 5 seconds
- 2. Take your old remote control and press 3 times the same button as follows, press for 1 second, release for 1 second (x3)
- 3. Wait for 2 seconds and press once any button in your new remote control
- 4. Your new remote control is now programmed!