



CAME AT 02

Press the pushbutton of an already saved transmitter for about 15 seconds, until the TX LED stays on

Within 20 seconds, press a pushbutton of the transmitter you want to add (fig. D).

Wait 20 seconds before using it! Repeat C and D for all the transmitters you want to add (up to a maximum of 25 per receiver)

NOTE: Every press of the pushbuttons must be made within 20 seconds of the previous one, otherwise the procedure in course will be interrupted; to intentionally terminate a procedure, press the CLEAR pushbutton for 1 second

