



**ALLO**  
REMOTECONTROL

## INSTRUCTIONS

### GIBIDI

#### Programming from an already programmed transmitter

1. Take your existing working remote control, press and hold in both buttons for approx. 5 seconds
2. Release the buttons
3. Take your new remote control and press the button you want to program
4. Your new remote control is now programmed

#### Programming on the receiver:

1. Locate the programming button inside your Gibidi gate control enclosure and press it briefly, an LED will flash on the receiver P.C.B., you now have 10 seconds to perform the next step.
2. Take the new transmitter and press the button that you wish to use to operate your receiver for one second.
3. Your new remote control is now programmed

Visit our website: [www.Alloremotecontrol.com](http://www.Alloremotecontrol.com)